Philips
Micro-Fiber cleaning cloth

Dry

SAC3502W

Clean your CD

Regular cleaning of your CD ensures optimum performance of your equipment. It is important to keep your CD clean and dust free. This micro fiber cloth safely removes dust and debris.

Enjoy a spotless screen

- Lint-free microfiber cloth cleans safely and thoroughly
- Lint-free, reusable, washable microfiber cloth

PHILIPS

Micro-Fiber cleaning cloth
Dry

SAC3502W/27

Specifications

Packaging dimensions
- Packaging dimensions (W x H x D): 14.6 x 9.5 x 1.3 cm
- Nett weight: .064 kg
- Gross weight: .068 kg
- Tare weight: .004 kg

Outer Carton
- Outer carton (L x W x H): 22.9 x 9.7 x 13.7 cm
- Nett weight: .384 kg
- Gross weight: .816 kg
- Tare weight: .432 kg

Highlights

Lint-free microfiber cloth
Safely and thoroughly clean your screen with this lint-free microfiber cloth, designed to eliminate dust, dirt and fingerprints without leaving anything behind.

Reusable, washable cloth
This reusable microfiber cloth may be washed gently in soap and water, then air dryed. You may use it over and over again.

Issue date 2014-02-07

Version: 1.1.3

12 NC: 8670 000 35285
UPC: 6 09585 14578 8

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com